



INSERT SS-100 AFTER CB-101, BEFORE T101 TRANSFORMER
AND WIRES GOING TO F102, S102 + B101

SINCE THIS AMP IS 230 VAC ONLY, THE SS-100
RETURN WIRE (BETWEEN C+D HOLES) GOES TO GROUND